

5-STEP GUIDE TO CHECKING TIRE PRESSURE

You can always visit a Kal Tire store near you for FREE air and pressure check, but if you're keen to learn how to do it yourself, here's an easy guide:



FIND THE RECOMMENDED PSI

Find your vehicle manufacturer's recommended tire pressure on a sticker on the driver's side door jamb or in your owner's manual. DO NOT use the MAX PSI listed on the sidewall of your tire. This is the maximum pressure, not the recommended pressure.



CHECK AT THE RIGHT TIME

Check your tire pressure when your tires are 'cold'—in the morning or a few hours after driving—for the most accurate reading.



USE A RELIABLE PRESSURE GAUGE

Whether you choose a stick, dial or digital tire pressure gauge, make sure it's accurate (tire gauges are sensitive to being dropped).

After you remove the valve cap on the tire, press the tire gauge onto the valve (ensuring you're not using the end that releases air). Now, wait for the press reading. For stick gauges, wait until the white plastic stick stops moving; on a dial gauge, wait for the needle to stop.



INFLATE AS NEEDED

Add just enough air to reach the recommended tire pressure. If you add too much, just push on the metal stem in the centre of the valve to release air.



REMEMBER YOUR SPARE

After you check and inflate all four of your tires, do the same for your spare to ensure it's ready to perform in the event of a flat tire.